

CARSUPPORT

CARSUPPORT STANDARD HEAVY DUTY
 11A01 11A01H

JEEP Cherokee 1984- with axle $\phi 67\text{mm}$

PARTS (x2)

- (1) auxiliary spring
- (2) upperplate/bumpstop
- (3) lower bumpstop
- (4) U-bolt
- (5) saddle
- (6) washer + nut (4 per set)

1. Jack up car until rear wheels are off the ground.
2. Replace original bumpstop by upperplate/bumpstop(2).
3. Place U-bolt(4) on axle beneath bumpstop(2) and slightly tighten with washer + nuts(6).
4. Place aux. spring(1) over upper bumpstop(2) with lower bumpstop(3) at the bottom. Push lower bumpstop(3) onto U-bolt(4).
5. Let car down and adjust U-bolts(4) to straighten aux. spring(1). Tighten nuts(6).

