

CARSUPPORT	<u>STANDARD</u>	<u>HEAVY DUTY</u>
	11A02	11A02H

JEEP Cherokee 1984- with axle  $\phi 77\text{mm}$

For axle  $\phi 67\text{mm}$  use 11A01(H).

PARTS (x2)

- (1) auxiliary spring
- (2) upperplate/bumpstop
- (3) lower bumpstop
- (4) U-bolt
- (5) saddle
- (6) washer (4 per set)
- (7) nut (4 per set)

1. Jack up car until rear wheels are off the ground.
2. Replace original bumpstop by upperplate/bumpstop(2).
3. Place U-bolt(4) on axle beneath bumpstop(2) and slightly tighten with washers(6) and nuts(7).
4. Place aux. spring(1) over upper bumpstop(2) with lower bumpstop(3) at the bottom. Push lower bumpstop(3) onto U-bolt(4).
5. Let car down and adjust U-bolts(4) to straighten aux. spring(1). Tighten nuts(7).

