

GRAYSTON ENGINEERING LIMITED

115 Roebuck Road • Chessington • Surrey KT9 1JZ • UK Telephone: 020 8974 1122 Fax: 020 8974 2288

CARSUPPORT

STANDARD

HEAVY DUTY

11C02

11C02H

MAKE:

TYPE:

YEAR:

JEEP

Grand Cherokee, type WJ

1999-

CAR HEIGHT

After fitting the rear of the car will raise:

- Standard set

approx. + 20 mm

- Heavy duty set

approx. +30 mm

PARTS

- (1) 2x upper seat
- (2) 2x bump stop
- (3) 2x auxiliary spring
- (4) 2x spring collar

INSTRUCTIONS

- 1. Disconnect lower end of rear shock absorbers.
- 2. Jack up rear of car, do not remove main springs.
- 3. Place spring collar(4) onto the original bumpstop.
- Screw widest end of auxiliary spring(3) down through upper side opening into the main spring.
- Place bump stop(2) and upper seat(1) into auxiliary spring(3).
- 6. Lower vehicle and re-connect shock absorbers.

