

CARSUPPORT	<u>STANDARD</u>	<u>HEAVY DUTY</u>
	14C04	14C04H

<u>MAKE:</u>	<u>TYPE:</u>	<u>YEAR:</u>
BMW	3 series E46	1998-

CAR HEIGHT

After fitting the rear of the car will raise:

- Standard set approx. + 20 mm
- Heavy duty set approx. + 30 mm

PARTS

- (1) 2x auxiliary spring
- (2) 2x collar

INSTRUCTIONS

1. Disconnect lower end of rear shock absorbers.
2. Jack up rear of car until springs are **almost** free.
There is no need to remove the main springs.
Attention: Do not stretch brakepipe.
3. Tilt end of auxiliary spring up through lowest side opening into the main spring.
4. Screw auxiliary spring(1) up into the main spring.
5. Place collar(2) on top of auxiliary spring(1)
6. Lower vehicle and fit auxiliary spring(1) between the original rubber spring seat.
7. Re-connect shock absorbers.