

**CARSUPPORT**      STANDARD  
 replaces            18C06  
                           18C04

<u>MAKE:</u>	<u>TYPE:</u>		<u>YEAR:</u>
Mercedes	W140	S-Klasse	93-98
Mercedes	W140	S-Klasse	98-

PARTS (x2)

- (1) 2x nylon lower seat
- (2) 2x auxiliary spring
- (3) 2x nylon upper seat
- (4) 2x extra fitting collar

INSTRUCTIONS

1. Remove plastic dustcover of the suspension arm.  
 Disconnect lower end of rear shock absorbers.
2. Jack up car.
3. Screw auxiliary spring(2) through the hole of the suspension arm, halfway up into the main spring.
4. Extra fitting collar(4):
  - a. old type 1993-98: place nylon upper seat(3) with collar(4) on top of auxiliary spring(2).
  - b. new type 1998→: place nylon upper seat(3) without collar(4) on top of auxiliary spring(2).
5. Screw auxiliary spring(2) further up until upper seat(3) fits properly into hole.
6. Lift lower side of auxiliary spring(2) and place lower seat(1) in the hole of the suspension arm.
7. Lower vehicle and re-connect shock absorbers.
8. Place plastic dustcover.

