

CARSUPPORT	<u>STANDARD</u>	<u>HEAVY DUTY</u>
	18C07	18C07H

<u>MAKE:</u>	<u>TYPE:</u>	<u>YEAR:</u>
Mercedes	E-Klasse W210 incl. T-model (Stationwagon)	1996-

CAR HEIGHT

After fitting the rear of the car will raise:

- Standard set approx. + 20 mm
- Heavy duty set approx. + 30 mm

PARTS

- (1) 2x nylon upper seat
- (2) 2x auxiliary spring
- (3) 2x lower seat

INSTRUCTIONS

1. Jack up rear of the car so that rear wheels are off the ground.
Remove plastic cover from suspension arm.
2. Unscrew nut of suspension arm bolt, support suspension arm below the bolt and remove the bolt. Lower suspension arm and remove main spring and rubber collar.
3. Clean suspension arm spring seat from dirt and place lower seat(3) in hole.
4. Place auxiliary spring(2) with nylon upper seat(1) on top in main spring and fit both springs.
5. Place bolt of suspension arm, do not tighten the nut yet, see 6. Place plastic cover.
6. Lower vehicle and tighten nut of suspension arm.

