

# GRAYSTON ENGINEERING LIMITED

115 Roebuck Road • Chessington • Surrey KT9 1JZ • UK  
Telephone: 020 8974 1122 Fax: 020 8974 2288

CARSUPPORT

STANDARD  
19C03

HEAVY DUTY  
19C03H

FIAT Punto 01/94-

E

## PARTS (x2)

- (1) auxiliary spring
- (2) rubber collar
- (3) lower seat
- (4) nut
- (5) upper seat

## INSTRUCTIONS

1. Disconnect lower end of rear shock absorbers.  
Jack up car until rear wheels are off the ground.
2. Remove original bumpstop rebound plate (not to be used when fitting kit).
3. Place lower seat(3) with the bolt in the hole of the lower main spring seat and turn high side(A) to the rear side of the car.  
Adjust with nut(4).  
Place rubber collar(2) onto seat(3).
4. Screw widest end of auxiliary spring up through lowest side opening into the main spring.  
Place seat(5) on top of auxiliary spring(1).
5. Lower the car and guide seat(5) over the original bump stop.
6. Re-connect shock absorbers.

