

CARSUPPORT

STANDARD

HEAVY DUTY

21A02

21A02H

FORD

Escort Van

80-90

E

PARTS (2x)

- (1) auxiliary spring
- (2) upper seat + bumpstop
- (3) bumpstop
- (4) U-bolt
- (5) saddle
- (6) washer (4 per set)
- (7) nut (4 per set)

1. Jack up car so that rear wheels are off the ground.
2. Position upper seat + bumpstop(2) with pin in existing hole of chassis member.
3. Place U-bolts(4) on axle, slightly tighten nuts(7). Assure sufficient brakepipe clearance.
4. Push top of aux. spring(1) over bumpstop(2) and bottom with bumpstop(3) on the lower seat.
5. Let car down, adjust U-bolts(4) to straighten aux. spring(1) and tighten nuts(7).

