

CARSUPPORT

EXTRA HEAVY DUTY

21A03E

MAKE: TYPE: YEAR:
FORD **Transit** **86-**

only for models with square rear axle

This extreme heavy duty set 21A03E is recommended for vehicles with permanent heavy load (motorhomes etc.).

For vehicles with variable loads (delivery vans etc.) the sets 21A03 and 21A03H are recommended.

E

PARTS

(1) bottom plate	x2
(2) bolt + washer + nut	x4
(3) lower bracket	x2
(4) bumpstop	x2
(5) auxiliary spring	x2
(6) upper seat + bumpstop	x2
(7) collar	x4

(A) rear axle

INSTRUCTIONS

1. Disconnect lower end of rear shock absorbers.
Jack up vehicle so that rear wheels are off the ground.
2. Remove original lock plate and bumpstop.
3. Install brackets(3) with bumpstop(4), bottom plate(1) and bolt + washer + nut(2).
Do not tighten nuts.
4. Place upper seat + bumpstop(6) with collar(7) on top of aux. spring(5).
Place aux. spring(5) over lower bumpstop(4) with second collar(7).
Position the pin of upper seat(6) into the hole of the original bumpstop.
5. Lower vehicle and re-connect shock absorbers
Adjust brackets(3) to straighten aux. spring(5).
Tighten nuts.
6. Loadsensing brake valve:
After fitting the auxiliary springs check and adjust the loadsensing brake valve as per Ford manual.

