



GRAYSTON ENGINEERING LIMITED

Manufacturers of Spring Assisters & Motor Accessories

**GRAYSTON ENGINEERING LIMITED**

115 Roebuck Road • Chessington • Surrey KT9 1JZ • UK  
Telephone: 020 8974 1122 Fax: 020 8974 2288

HEAVY DUTY

21A04H

FORD Escort Van 90-

**E**

PARTS (x2)

- (1) auxiliary spring
- (2) upper plate + bumpstop
- (3) bumpstop
- (4) U-bolt + saddle L/R
- (5) washer + nut (4 per set)

1. Jack up car so that rear wheels are off the ground.
2. Position L/R upper seat + bumpstop(2) with pin in existing hole of chassis traverse member.
3. install U-bolts(4) and L/R U-bolt saddles (slotted side at the rear). Do not tighten nuts(5). Assure sufficient brakepipe clearance.
4. Push aux. spring(1) over bumpstop(2), bumpstop(3) at the bottom end on the lower seat.
5. Let car down, adjust U-bolts(4) to straighten aux. spring(1) and tighten nuts.

