

CARSUPPORT

STANDARD

HEAVY DUTY

FORD	Scorpio	1995-	21A11	21A11H
FORD	Scorpio Wagon	1995-	21A13	21A13H

E

PARTS (x2)

- (1) bumpstop
- (2) steel collar
- (3) auxiliary spring
- (4) rubber cap
- (5) lower seat
- (6) rubber collar

INSTRUCTIONS

1. Jack up car until rear wheels are off the ground.
2. Replace original upper bumpstop (next to the main spring) by bumpstop(1).
3. Place lower seat(5) with rubber cap(4) on top and rubber collar(6) at the bottom with the bolt in the hole of the suspension arm.
4. Guide auxiliary spring(3) with steel collar(2) on top over bumpstop(1) and push the lower side onto rubber cap(4).

