

<u>CARSUPPORT</u> <u>DUTY</u>	<u>STANDARD</u>	<u>HEAVY</u>
	21C05	21C05H
FORD	Escort Clipper	90-
FORD	Escort Wagon	95-
FORD	Taurus Wagon	86-
MERCURY	Sable Wagon	86-

## E

### PARTS (2x)

(1) auxiliary spring

### CLIPPER

1. Disconnect lower end of rear shock absorbers.
2. Jack up rear of car until springs are almost free.  
There is no need to remove the main springs.
3. Screw auxiliary spring up through lowest side opening into the main spring.
4. Re-connect shock absorbers.

### TAURUS / SABLE

1. Disconnect brakepipe bracket (L/R) and stabilizer bar support (L/R).
2. Disconnect lower end of rear shock absorbers.
3. Jack up rear of car until springs are almost free.  
There is no need to remove the main springs.
4. Screw auxiliary spring up through lowest side opening into the main spring.
5. Re-connect brakepipe brackets, stabilizer bar supports and shock absorbers.