

CARSUPPORT STANDARD HEAVY DUTY
 21C07 21C07H

MAKE: TYPE: YEAR:
Ford Fiësta 2002-

CAR HEIGHT

After fitting the rear of the car will raise:

- Standard set approx. + 20 mm
- Heavy duty set approx. + 30 mm

PARTS

- (1) 2x upper seat
- (2) 2x auxiliary spring
- (3) 2x lower seat

INSTRUCTIONS

1. Disconnect lower end of rear shock absorbers.
2. Jack up rear of car until springs are **almost** free.
There is no need to remove the main springs
3. Screw **widest end** of auxiliary spring up through **lowest** side opening into the main spring.
4. Place bottom seat(3) in hole of the suspension arm.
5. Place upper seat(1) on top of auxiliary spring(2).
6. Lower vehicle and re-connect rear shock absorbers.

