

CARSUPPORT	<u>STANDARD</u>	<u>HEAVY DUTY</u>
	23S05	23S05H

HONDA Legend	type KA7	91-
HONDA Legend Coupé	type KA8	91-

E

PARTS (x2)

- (1) steel cap
- (2) bumpstop
- (3) rubber ring
- (4) auxiliary spring
- (5) spring seat + bellow
- (6) large steel collar
- (7) rubber collar
- (8) small steel collar

(A) original steel ring

1. Jack up car until rear wheels are off the ground.
2. Remove rear wheels.
3. Remove strut (behind back seat).
4. Remove main spring, ring(A), dust cover and bumpstop.
5. Fit parts as shown.
6. Re-install main spring and complete strut.

