

CARSUPPORT STANDARD HEAVY DUTY
 23S07 23S07H

MAKE: TYPE: YEAR:
Honda Accord incl. Coupe 2000-
Code CG7,CG8,CG9,CH6,CH7,CG2,CG4

CAR HEIGHT

After fitting the rear of the car will raise:

- Standard set approx. + 20 mm
- Heavy duty set approx. + 30 mm

PARTS

- (1) 2x centring collar
- (2) 2x auxiliary spring
- (3) 2x rubber ring
- (4) 2x tube part with dustcover and spring seat

- (A) original steel ring
- (B) original bump stop

INSTRUCTIONS

1. Remove rear seat:
Pull up front of bottom of rear seat and remove it.
Disconnect brackets on both sides of back of rear seat (key 10).
Tilt back of rear seat forward and remove both side parts.
2. Remove plastic cover of the struts.
Disconnect upper end of struts (2x key 14).
3. Jack up car, remove rear wheels.
4. Disconnect upper part of stabilizer bar.
Disconnect lower end of strut and remove it.
5. Remove original spring seat and spring.
ATTENTION: use spring compressor.
6. Remove original dust cover (not to be re-used), ring(A) on bump stop(B).
7. Place part (3), (4), (2), (B), (A) and centring collar(1).
Place original spring and spring seat.
8. Re-install strut.
9. Re-install rear seat.

