

27C01 STANDARD / 27C01H HEAVY DUTY

M A Z D A 626 78-83

GB

PARTS LIST

- (1) auxiliary spring
- (2) upper rubber collar
- (3) upper spring seat
- (4) lower rubber collar
- (5) lower spring seat
- (6) nut

INSTRUCTIONS

1. Disconnect lower end shock absorbers at the rear.
2. Jack up rear of car. Pay attention to brake hose - do not stretch! Remove main springs.
3. Drill a hole of \varnothing 8 mm through the centre of lower main spring seat.
4. Insert aux. spring(1) narrow end up with parts(2,3,4,5,6) inside main spring. Install spring assembly on car.
5. Re-connect shock absorbers and tighten nuts(6).

NL

ONDERDELEN

- (1) hulpveer
- (2) rubber bovenkraag
- (3) boven veerschotel
- (4) rubber onderkraag
- (5) onder veerschotel
- (6) moer

INBOUWVOORSCHRIFT

1. Achterschokdempers onder losnemen.
2. Achterzijde auto opkrikken. Let op remslang - niet op trek belasten! Hoofdveren verwijderen.
3. Boor een gat van \varnothing 8 mm in het midden van de hoofdveer onderschotel.
4. Plaats hulpveer(1) met onderdelen(2,3,4,5,6) in de hoofdveer, wijde kant hulpveer(1) onder. Monteer het geheel onder de auto.
5. Schokdempers en moeren(6) vastzetten.

