

27C02 STANDARD / 27C02H HEAVY DUTY

M A Z D A 929 excl. Estate/Station 78-81 coil springs
schroefveren

GB

PARTS LIST

- (1) auxiliary spring
- (2) upper spring seat
- (3) lower spring seat

INSTRUCTIONS

1. Disconnect lower end shock absorbers at the rear.
2. Jack up rear of car until top of main spring is free.
Tilt top backwards and install parts (3,1,2) inside main spring. Wide end spring(1) up.
3. Re-position main spring.
4. Re-connect lower end shock absorbers.

NL

ONDERDELEN

- (1) hulpveer
- (2) boven veerschotel
- (3) onder veerschotel

INBOUWVOORSCHRIFT

1. Achterschokdempers onder losnemen.
2. Achterzijde auto opkrikken tot bovenkant hoofdveer vrijkomt.
Trek bovenkant naar achteren en plaats onderdelen(3,1,2). Wijde kant hulpveer (1) boven.
3. Plaats hoofdveer in juiste positie.
4. Schokdempers vastzetten.

