

**MITSUBISHI**  
SPACE WAGON 91-

SETNR.  
STANDARD 28C09  
HEAVY DUTY 28C09H

- PARTS LIST (x2)
- (1) auxiliary spring
  - (2) lower seat
  - (3) nylon upper seat

INSTRUCTIONS

1. Disconnect lower end of rear shock absorbers.
  2. Disconnect upper side of arm of loadsensing brake valve.
  3. Jack up car and remove rear main springs.
  4. Place lower seat(2) in hole of the suspension arm.
  5. Insert aux. spring(1) with nylon upper seat(3) on top, inside main spring and fit the assembly.
- Please note:  
Seat(3) with flat edge to the front.
6. Re-connect arm of loadsensing brake valve.
  7. Re-connect shock absorbers.

