

AUX. SPRINGS    ST: STANDARD    HD: HEAVY DUTY  
Carsupport    28C16    28C16H

<u>MAKE:</u>	<u>TYPE:</u>	<u>YEAR:</u>
Mitsubishi	Outlander	'07-'10
Citroën	C-Crosser	'07-'12
Peugeot	4007	'07-'12

CAR HEIGHT

After fitting the rear of the car will raise:

- Standard set    approx. + 20 mm
- Heavy duty set    approx. + 30 mm

LOCATION (see letter in set number)

"C": inside main spring

PARTS

- (1) 2x auxiliary spring
- (2) 2x upper seat
- (3) 2x lower seat

INSTRUCTIONS

1. Jack up car and remove rear wheels.
2. Disconnect lower end of rear shock absorbers.  
From anti-roll bar disconnect nut (key 12) on top and release joint (L and R-side).
3. Support wheel side of suspension arm and remove bolt. Lower suspension arm.
4. Remove main spring.
5. Place aux. spring(1) with upper seat and lower seat into main spring. Fit the assembly.
6. Lift and re-connect suspension arm, anti-roll bar and shock absorber.
7. After fitting protect all the steel parts including springs with a corrosion resisting coating like Tectyl.

