

31B01 STANDARD

31B01H HEAVY DUTY

PEUGEOT 504,505,604

NL

ONDERDELEN

- (1) hulpveer
- (2) veerkraag
- (3) onderplaat met veerschotel

GB

PARTS LIST

- (1) auxiliary spring
- (2) upper seat
- (3) bottom plate with seat

NL

INBOUWVOORSCHRIFT

1. Auto achter opkrikken tot achterwielen vrijkomen.
2. Schuif onderplaat(3) bij wijze van proef op de draagarm, met de veerschotel onder de aanslagbuffer en de bouten tegen de rand. NIET BOREN. Draai de bouten zo ver aan totdat plaat(3) nog juist geschoven kan worden. Verwijder plaat(3).
3. Zet veerkraag(2) bovenin hulpveer(1) en plaats (1) op de veerschotel van de onderplaat(3). Druk veer(1) met kraag(2) op de aanslagbuffer en schuif de onderplaat (3) op de draagarm met bouten tegen de rand. Laat auto neer en controleer of positie van (3) en (1) correct is. Bouten vastzetten.

GB

INSTRUCTIONS

1. Jack up rear of car so that rear wheels are off the ground.
2. Install lower plate(3) preliminary onto suspension arm with its seat underneath rubber buffer and bolts against edge. DO NOT DRILL. Tighten bolts so far that plate(3) just can be shifted. Remove plate(3).
3. Place spring(1) onto seat of bottom plate(3) with seat ring(2) on top. Push spring(1) with ring(2) over original buffer and locate bottom plate(3) onto suspension arm, bolts against edge. Let car down. Check correct position (3) and (1). Tighten bolts.

