

CARSUPPORT	STANDARD	HEAVY DUTY
	31B09	31B09H

MAKE:	TYPE:	YEAR:
CITROËN	ZX	91-
CITROËN	Xsara incl. Break	97-
PEUGEOT	306	93-97
PEUGEOT	306 incl. Break	97-

PARTS

- (1A) 2x collar ø54mm
- (1B) 2x collar ø51mm
- (2) 2x auxiliary spring
- (3) 2x bump stop
- (4) 2x bracket (L/R)
- (5) 2x bolt
- (6) 2x washer
- (7) 2x nut

(A) original black or yellow bump stop

INSTRUCTIONS

1. Disconnect upper end of rear shock absorber
2. Jack up car. **Attention:** Do not stretch brakepipe.
3. Install left-/right-hand side bracket(4) (see table) in the profiled part of the L/R suspension arm.

Make	Type	Left	Right
Citroën	ZX	4.a	4.b
Citroën	Xsara	4.b	4.a
Peugeot	306 chass.nr. ←...32000000	4.a	4.b
Peugeot	306 incl. Break chass.nr. →...32000000	4.b	4.a

Make sure the brakepipe is on the outside of the bracket. Check if bracket(4) is fitted with high side to the back of the car.

4. Fit bracket(4) with bolt(5) with washer(6) and nut(7).

Fig. 1: Original black bumpstop:

Push collar(1A) with **flat side facing down** over the original bumpstop(A).

Fig. 2: Original yellow bumpstop:

Place collar(1B) with **flat side facing up** into auxiliary spring(2).

6. Place bump stop(3) in lower side of spring(2). Shift spring(2) over original bumpstop(A). Press spring(2) up and place bump stop(3) on bracket(4).

7. Re-install shock absorber.

Lower vehicle and check installation of springs.

8. Cars with loadsensing brake valve:

After fitting the auxiliary springs check and adjust the loadsensing brake valve according to car-manufacturer's manual.

