

CARSUPPORT	<u>STANDARD</u>	<u>HEAVY DUTY</u>
	31C05	31C05H

<u>MAKE:</u>	<u>TYPE:</u>	<u>YEAR:</u>
Peugeot	307	2001-

CAR HEIGHT

After fitting the rear of the car will raise:

- Standard set approx. + 15 mm
- Heavy duty set approx. + 25 mm

PARTS

- (1) 2x upper seat
- (2) 2x auxiliary spring
- (3) 2x lower seat

INSTRUCTIONS

1. Disconnect the lower end of rear shock absorbers.
2. Jack up rear of car until springs are almost free.
There is **no** need to **remove** the main springs.
3. Screw the narrow end of auxiliary spring(2) up through lowest side opening into the main spring.
4. Place lower seat(3) into hole of suspension arm and upper seat(1) on top of auxiliary spring(2).
5. Lower vehicle and re-connect shock absorbers.

