

**CARSUPPORT**      STANDARD      HEAVY DUTY  
                                  **32C08**                      **32C08H**

**MAKE:**      **TYPE:**                      **YEAR:**  
**Renault**      **Laguna incl. Grand Tour**      **01-07**

CAR HEIGHT

After fitting the rear of the car will raise:  
 - Standard set      approx. + 20/25 mm  
 - Heavy duty set      approx. + 30/35 mm

PARTS

- (1) 2x locknut M10
  - (2) 2x spacer
  - (3) 2x upper seat
  - (4) 2x rubber cap
  - (5) 2x auxiliary spring
  - (6) 2x lower seat
  - (7) 2x fitting plate
  - (8) 2x centring plate
  - (9) 2x plain washer M8
  - (10) 4x locknut M8
  - (11) 2x large washer M8
- (A) original spring seat
  - (B) hole in suspension arm
  - (C) original plastic cover

INSTRUCTIONS

1. Remove plastic covers from suspension arms.  
**Please note!:** there are two different covers:  
 a. Small cover (covers only part with spring seat, no clips in the hole in suspension arm(B)).  
 Drill a hole of  $\varnothing 10\text{mm}$  in the centre of the circle in the cover.  
 b. Large cover (covers a large part of the suspension arm, attached with 3x clips in hole of suspension arm(B)).  
 Drill a hole of  $\varnothing 15\text{mm}$  in the centre between the three clips and remove the three clips.
2. Jack up rear of car, do not remove main springs.
3. Remove dirt from topside of original spring seat(A) and place upper seat(3) from below in the hole of spring seat(A).  
**Attention:** place with cap facing to the rear of the car.  
 Secure with spacer(2) and locknut M10 (1).
4. Screw end of auxiliary spring(5) up through lowest side opening into the main spring.
5. Place (7), (6)\*, (8), (9) and slightly tighten with locknut(10).  
 \* **Attention:** position lower seat(6) with the high side facing the rear of the car.
6. Let car down and check the clearance of the aux. spring(5), if necessary enlarge clearance by turning lower seat(6).
7. Tighten locknuts(10).
8. Place plastic covers(C) onto suspension arms.  
 a. Small cover: studbolt of lower seat(6) though drilled hole.  
 b. Large cover: secure cap with large washer(11) and locknut(10).

