

A U D I 100

38C01 STANDARD / 38C01H HEAVY DUTY

GB

<u>PARTS LIST</u>	(1) auxiliary spring	(4) aux. spring seat
	(2) nut	(5) upper rubber collar
	(3) lower rubber collar	

### INSTRUCTIONS

1. Disconnect lower end shock absorbers at the rear.
2. Jack up rear of car until top of main spring is free.  
Tilt top of main spring backwards and install seat(4) with rubber collar(3) on lower main spring seat.
3. Install aux. spring(1) with upper rubber collar(5) on the narrow spring end on top of rubber collar(3).  
Re-position main spring.  
Turn seat(4) until the mark (higher part) is at the rear.
4. Re-connect lower end shock absorbers and tighten nuts(2)

NL

<u>ONDERDELEN</u>	(1) hulpveer
	(2) moer
	(3) rubber onderkraag
	(4) hulpveerschotel
	(5) rubber bovenkraag

### INBOUWVOORSCHRIFT

1. Achterschokdempers onder losnemen.
2. Achterzijde auto opkrikken tot bovenzijde hoofdveer vrijkomt.  
Trek bovenkant naar achteren en plaats schotel(4) met rubberkraag(3) op de onderste hoofdveerschotel.
3. Plaats rubberkraag(5) op het nauwe hulpveer-einde en zet hulpveer(1) met de wijde kant op rubberkraag(3) in de hoofdveer.  
Kantel hoofdveer weer in juiste positie.  
Draai schotel(4) tot het merkteken (hoge kant) achter staat.
4. Schokdempers en moeren(2) vastzetten.

