

CARSUPPORT	<u>STANDARD</u>	<u>HEAVY DUTY</u>
	38C05	38C05H

<u>MAKE:</u>	<u>TYPE:</u>	<u>YEAR:</u>
VW	Passat IV	97-
Audi	A6	97-

PARTS

- (1) 4x rubber spring seat
- (2) 2x spring collar
- (3) 2x auxiliary spring

INSTRUCTIONS

1. Disconnect lower end of rear shock absorbers.
2. Jack up car until springs are almost free. There is no need to remove the main springs.
3. Place one rubber spring seat (1) over the original rubber spring seat at the bottom of the main spring.
4. Screw widest end of auxiliary spring(3) up through lowest side opening into the main spring.
5. Place parts (2) and (1) on top of auxiliary spring(3).
6. Re-connect shock absorbers.

