

CARSUPPORT	<u>STANDARD</u>	<u>HEAVY DUTY</u>
	38C07	38C07H

<u>MAKE:</u>	<u>TYPE:</u>	<u>YEAR:</u>
Ford	Galaxy	1996-
Seat	Alhambra	1996-
VW	Sharan	1995-

CAR HEIGHT

After fitting the rear of the car will raise:

- Standard set approx. +20 mm
- Heavy duty set approx. +30 mm

PARTS

- (1) 2x nylon spacer
- (2) 2x auxiliary spring

- (A) attachment for original bumpstop
- (B) original bumpstop

INSTRUCTIONS

1. Disconnect lower end of rear shock absorbers.
2. Jack up rear of car, do *not* remove main springs.
Attention: Do not stretch brakepipe.
3. Remove original bumpstop(B), key 41mm.
4. Place spacer(1) with original bumpstop(B).
5. Screw end of auxiliary spring up through lowest side opening into the main spring.
6. Lower car and guide auxiliary spring over bumpstop(B).
7. Reconnect shock absorbers.

