

<b>CARSUPPORT</b>	<u>STANDARD</u>	<u>HEAVY DUTY</u>
	38C10	38C10H

<u>MAKE:</u>	<u>TYPE:</u>	<u>YEAR:</u>
Audi	A4 incl. Avant excl. Quattro 4x4	2001-

CAR HEIGHT

After fitting the rear of the car will raise:

- Standard set approx. + 15 mm
- Heavy duty set approx. + 25 mm

LOCATION (see letter in set number)

"C": inside main spring

PARTS

- (1) 2x upper seat
- (2) 2x auxiliary spring
- (3) 2x lower seat

INSTRUCTIONS

1. Disconnect lower end of rear shock absorbers.
2. Jack up car and remove rear wheels.  
(There is no need to remove the main springs)
3. Place lower seat(3) in hole of the suspension arm.
4. Screw end of auxiliary spring(2) from the wheel side down through upper side opening into the main spring.
5. Re-attach rear wheels and lower the car.
6. Connect lower end of rear shock absorbers.

