

CARSUPPORT

STANDARD
39C05

HEAVY DUTY
39C05H

VOLVO 440 series
VOLVO 460 series

GRAYSTON ENGINEERING LIMITED
115 Roebuck Road • Chessington • Surrey KT9 1JZ • UK
Telephone: 020 8974 1122 Fax: 020 8974 2288

*** Attention:**

Chassis number up to 14063 :
Replace original bumpstop rebound plastic part(A) with Volvo part number 3445928-9 (2x).

E

PARTS (2x)

- (1) auxiliary spring
- (2) lower seat
- (3) upper seat

- (A) original bumpstop rebound plastic part
- (B) original **black** bumpstop, see FIG. 1
- original **yellow** bumpstop, see FIG. 2

1. Disconnect lower end of rear shock absorbers.
2. Jack up rear of car, do not remove main springs.
Do not stretch brakepipe.
3. **Yellow** bumpstop FIG. 2:
push upper seat(3) over yellow bumpstop(B)

Black bumpstop FIG. 1:
upper seat(3) not to be used.

4. Place lower seat(2) over original bumpstop rebound plastic part(A).
See note *.
5. Screw end of auxiliary spring(1) up through lowest side opening into the main spring.
6. Re-connect shock absorbers.

