

CARSUPPORT      STANDARD  
                            45C04

MAKE:            TYPE:                            YEAR:  
Kia                Sorento                            2002-

#### CAR HEIGHT

After fitting the rear of the car will raise:  
- Standard set            approx. + 20 mm

LOCATION (see letter in set number)

"C": inside main spring

#### PARTS

- (1) 2x upper seat
- (2) 2x auxiliary spring
- (3) 2x rubber cap
- (4) 2x lower seat

#### INSTRUCTIONS

1. Disconnect lower end of rear shock absorbers.
2. Jack up rear of car, do **not** remove main springs.  
Attention: Do not stretch brakepipe and ABS-cable.
3. Place lower seat(4) and rubber cap(3) in the hole of the original spring seat.
4. Screw end of auxiliary spring(2) up through **lowest** side opening into the main spring.
5. Place upper seat(1) onto auxiliary spring(2).
6. Lower vehicle and re-connect shock absorbers.

