

ST: STANDARD HD: HEAVY DUTY EHD: EXTRA HEAVY DUTY

51C03 51C03H 51C03E

MAKE:	TYPE:	YEAR:
Citroën	Jumpy, Dispatch	07-
Fiat	Scudo	07-
Peugeot	Expert	07-

CAR HEIGHT

After fitting the rear of the car will raise:

- Standard set approx. + 15 mm
- Heavy duty set approx. + 20 mm
- Extra heavy duty approx. + 30 mm

LOCATION (see letter in set number)

"C": inside main spring

PARTS

- (1) 2x steel upper spring collar
- (2) 2x auxiliary spring
- (3) 2x nylon lower spring seat (51C03E: with steel collar)
- (A) original rubber upper spring seat



INSTRUCTIES

1. Jack up the car and remove the rear wheels.
2. Support the suspension arm and disconnect the lower end of the rear shock absorbers.
3. Lower the suspension arm until the main springs are almost free.
Do **not** remove original rubber upper spring seat(A)
4. Screw auxiliary spring(2) up through the lowest side opening into the main spring.
Place spring seat(3) in the hole of the original lower spring seat and place spring collar(1) on top of auxiliary spring(2).
5. Jack up the suspension arm and guide upper spring collar(1) into the hole of original upper spring seat(A). Re-connect the lower end of the shock absorbers hand tight.
Jack up the suspension arm further until the full weight of the rear of the car is carried by the springs, fully tighten the lower end of the shock absorber and lower the suspension arm.
Reinstall the wheels, lower the car.
6. After fitting protect all the steel parts including springs with a corrosion resisting coating like Tectyl.
Note: Avoid spraying on rubber or plastic parts of the kit or the vehicle.



Figuur 10



Figuur 11



Figuur 12



Figuur 13



Figuur 14