

CARSUPPORT EXTRA HEAVY DUTY KIT: KR6104E

ATTENTION:

- This EHD-kit is especially designed for motorhomes and other permanent heavy loaded cars.
The permanent rear axle load must be minimal 1300kg.
For less heavy loaded cars other aux.spring sets are available. See our catalogue.
- This set is intended for cars with leaf springs.
For an AL-KO torsion-axle are other sets available, see our camper catalogue.
- For the front side special replacement springs are available, which will raise the front 4-6cm!

| <u>MAKE:</u> | <u>TYPE:</u> | <u>YEAR:</u> |
|--------------|--------------|--------------|
| Citroën | Jumper | '06- |
| Fiat | Ducato | '06- |
| Peugeot | Boxer | '06- |

CAR HEIGHT

After fitting the rear of the car will raise + 4 to + 6 cm.

LOCATION (see letter in set number)

"B": on position of bump stop

PARTS

- (1) 2x upper seat
- (2) 2x auxiliary spring
- (3) 2x lower seat

- (A) original bump stop
- (B) original U-bolts

INSTRUCTIONS

1. Disconnect lower end of rear shock absorbers.
2. Jack up car until the rear wheels are several centimetres off the ground.
3. Place a jack between the leaf spring and the chassis.
Push the leaf spring several centimetres down.
Attention: do not stretch the brake hose.
4. Place auxiliary spring(2) and upper seat(1) over original bump stop(A).
5. Place lower seat(3) onto the leaf spring between U-bolts(B) below spring(2).
6. Remove the jack and lower the car
7. Reconnect shock absorbers.

