

GRAYSTON ENGINEERING LIMITED

115 ROEBUCK ROAD,
CHESSINGTON, SURREY KT9 1JZ, U.K.
Telephone: 0181-974 1122
Facsimile: 0181-974 2288

23S04.E02

CARSUPPORT STANDARD
23S04

HONDA Accord type CB 89-
HONDA Accord Europe type CC3 93-

E

PARTS (x2)

- (1) steel ring
- (2) steel cap
- (3) bumpstop
- (4) rubber ring
- (5) auxiliary spring
- (6) U-shaped spring seat
- (7) spring seat tube + bellow
- (8) spring seat

(A) original steel ring

1. Jack up car until rear wheels are off the ground.
2. Remove rear wheels.
3. Remove strut (behind back seat).
4. Remove main spring, ring(A), dust cover and bumpstop.
5. Fit parts as shown.

ATTENTION :

spring seat(8) only to be used for Accord Europe typecode CC3, not for typecode CB

6. Re-install main spring and complete strut.

