

CARSUPPORT	STANDARD	HEAVY DUTY
	18A02	18A02H

MAKE:	TYPE:	YEAR:
Mercedes	Sprinter	1996-
VW	LT 28, LT 35	1997-

GRAYSTON ENGINEERING LIMITED
 115 Roebuck Road • Chessington • Surrey KT9 1JZ • UK
 Telephone: 020 8974 1122 Fax: 020 8974 2288

Not intended for vehicles with stabilizer bar

CAR HEIGHT

After fitting the rear of the car will raise:

- Standard set approx. +25 mm
- Heavy duty set approx. +35 mm

PARTS

- (1) 2x upper plate
- (2) 8x bumpstop
- (3) 4x auxiliary spring
- (4) 4x U-bolt
- (5) 2x lower plate
- (6) 8x plain washer M10
- (7) 8x self locking nut M10

INSTRUCTIONS

1. Jack up car until rear wheels are off the ground.
2. Place lower plate(5) beneath the rear axle. Locate with U-bolts(4), plain washers(6) and locking nuts(7). Place the tubes over the studpins of the leaf spring U-bolts.
3. Release bracket of parking brake. Turn it down until the cable has sufficient clearance from the springs(3). Tighten bracket.
4. Place upper plate(1) over the original bumpstop with the seats facing the wheel side.
5. Place lower bumpstops(2) and install auxiliary springs(3) with upper bumpstop(2) in the seat of the upper plate(1).
6. Adjustment loadsensing brake valve:
 After fitting the auxiliary springs check and adjust the loadsensing brake valve as per car-manufacturer's manual. The information is available near the First-aid kit in the right hand door panel.

