

CARSUPPORT      STANDARD      HEAVY DUTY  
                         18C08                      18C08H

MAKE:      TYPE:

Mercedes Vito

Mercedes Viano

Not intended for cars with self levelling system

YEAR:

2004-

2004-

CAR HEIGHT

After fitting the rear of the car will raise:

- Standard set      approx. +20 mm
- Heavy duty set      approx. +30 mm

LOCATION (see letter in set number)

"C": inside main spring

PARTS

- (1) 2x self locking nut M8
- (2) 2x plain washer M8
- (3) 2x spacer
- (4) 2x bumpstop fitting
- (5) 2x bolt M8x50
- (6) 2x auxiliary spring
- (A) original upper seat
- (B) original spring
- (C) original bumpstop
- (D) original lower seat

INSTRUCTIONS

1. Jack up car until rear wheels are almost off the ground.
2. Disconnect lower end of rear shock absorbers and lift car until rear wheels are off the ground.  
**Attention:** Do not stretch brakepipe.
3. Remove original spring(B) and original upper seat(A).
4. Remove original bumpstop(C) from original upper seat(A).
5. Place spacer(3) and bumpstop fitting(4) with bolt(5), plain washer(2) and self locking nut(1) in original upper seat(A).
6. Push original bumpstop(C) on bumpstop fitting(4).
7. Screw auxiliary spring(6) in original spring(B) as shown in Fig.2.
8. Place upper seat(A) in original spring(B) and auxiliary spring(6) and fit the assembly.
9. Lower vehicle and re-connect shock absorbers.




Fig 2




Fig. 2